



## Camera

- A Shutter Button
- B Lens
- C Flash
- D Viewfinder
- E Photo Eject Slot
- F Film Door Button
- G Flash Button
- H ON | OFF Button
- I Film Counter Display
- J Neck Strap Loop
- K USB Charging Port & Battery Level Indicator
- L +Button Mode Indicator
- M +Button
- N Light Meter
- O Tripod Mount

## Filters

- P Starburst
- Q Red Vignette
- R Yellow
- S Orange
- T Blue

## Battery

- Battery full
- Battery half full
- Battery empty

## +Button

The Polaroid Now+ camera is always ready to connect to the mobile app. Check the connection status with the +Button.

- Camera is searching for the mobile app.
- Camera is connected to the mobile app.
- Camera is not connected to the mobile app.

The lights above the +Button indicate which creative mode you're in.

- Self-timer: Press +Button once to activate.
- Double exposure: Double press +Button to activate.
- Custom shortcut: Long press +Button to activate.

Works with the free Polaroid mobile app



This camera works with



I-TYPE FILM

600 FILM

Have a problem or question?

USA/Canada  
usa@polaroid.com  
+1-212-219-3254

Contact our Customer Support Team

EU/Rest of World  
service@polaroid.com  
00800 5770 1500

or visit [polaroid.com/help](https://polaroid.com/help)

Apple and the App Store logo are trademarks of Apple Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google LLC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Polaroid International B.V. is under license. Other trademarks and trade names are those of their respective owners.



# Polaroid Now+

## Quick Start Guide

- 1 Turn on the Polaroid Now+ camera by pressing the ON | OFF button.
- 2 Download the Polaroid app to your mobile phone from the Apple App Store or Google Play store. Switch on Bluetooth® wireless technology. Open the app and tap 'Now+' from the menu. A permission message will pop up. Tap 'OK' to confirm. The +Button on the camera will turn blue to indicate that it's now connected to your phone\*.
- 3 To insert the film pack, open the film door.
- 4 Insert the film pack darkslide up and with the tab facing toward you.
- 5 Close the film door. The darkslide covered by the film shield will eject.
- 6 Do not pull on the film shield. Allow it to roll back into the camera, so you can remove the darkslide. You're now ready to take your first photo.
- 7 The Polaroid Now+ camera comes with a lens filter kit. To add a colored filter, press it over the lens. For the starburst and red vignette filters, turn until the small notch aligns with the light meter at the bottom of the lens. The filter will then click into place.
- 8 The Polaroid app comes with extra creative tools. Select one to use now, or continue to step 9.
- 9 Aim the camera at your subject and press the shutter button. The flash will trigger automatically.
- 10 To shoot without the flash, press the flash button before each shot.
- 11 The photo covered by the film shield will eject.
- 12 Don't shake the photo! Place your photo in a dark place or face down on a flat surface. Follow the development time on the packaging.



Download the complete  
Polaroid Now+ User Manual.

→ [polaroid.com/nowplus-manual](https://polaroid.com/nowplus-manual)

\*The connection is made through the app, so there's no need to pair the camera with your phone. This means the Polaroid Now+ camera will not appear in your phone's list of Bluetooth® devices.

Made in China for and distributed by Polaroid International B.V., 1013 AP, Amsterdam, The Netherlands. The POLAROID word and logos (including the Polaroid Classic Border Logo) and Polaroid Now are protected trademarks of Polaroid.  
©2022 Polaroid. All rights reserved.

