


Polaroid Lab

Before you get started.



I
Charge the Polaroid Lab before use




III
The Polaroid Lab is compatible with Polaroid i-Type and Polaroid 600 type film

II
The Polaroid Lab only works with the Polaroid app. Download it from the App Store or Google Play Store




IV
For best results, remove the screen protector and cover from your smartphone. Check that your phone's screen is clean. Cracks and scratches on your screen will influence picture quality




Quick Start Guide


Phone to Polaroid™




01 Remove the cover from the platform. **Turn the Polaroid Lab on by pressing the platform release button on the right side of the Lab.** The phone platform will automatically lift into ready position. Check that the rainbow LED is lit up.




02 Gently pull down on the film door to open it.




03 Insert the film pack with the darkside cover facing up. **Use only Polaroid i-Type or Polaroid 600 type film.**




04 **Close the film door.** The darkside will eject automatically beneath the film shield. Lift the film shield and allow it to roll back up, then remove the darkside.




05 Open the Polaroid app and tap on the 'Polaroid Lab' option. **Follow the instructions on the app to select the picture that you would like to use.**




06 Place your phone on the Polaroid Lab platform with the screen facing down. **Ensure that your phone is aligned lengthways and the top of your phone is facing the top of the platform.** Remove any screen protector or phone cover, as this can impair final results.



07 The Polaroid Lab will detect your phone on the platform. The rainbow LED will slowly blink three times and then stay on. If the rainbow LED blinks rapidly, realign your phone. **Once the blinking stops, press the red shutter button on the front of the Polaroid Lab.**



08 **Your photo will eject beneath the film shield.** After five seconds, lift the film shield, allow it to retract into the Polaroid Lab and then gently remove your photo.



09 **Don't shake or bend the photo!** Shield it from light (in a pocket, or face down on a flat surface) until the image begins to emerge - black & white photos take 5-10 minutes, while color pictures take 10-15 minutes.



Have a question you need answered?

Contact our Customer Support Team

or visit polaroid.com/help

USA/Canada
usa@polaroid.com
+1-212-219-3254

EU/Rest of World
service@polaroid.com
00800 5770 1500

Made in China for and distributed by Polaroid Film B.V. (P.O. Box 242, 7500 AE), Enschede, The Netherlands.

Polaroid, Polaroid Lab and Phone to Polaroid as well as the logos the Polaroid Color Spectrum and the Polaroid Classic Border Logo are trademarks of PLR IP Holdings, LLC, which is part of the Polaroid group of companies. PLR IP Holdings, LLC does not manufacture this product or provide any Manufacturer's warranty or support.

© 2020 Polaroid. All Rights Reserved.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

Download on the App Store

GET IT ON Google Play

Polaroid Lab

Check your Polaroid Lab charge level





The battery level is displayed on four LEDs above the USB slot at the back of the Polaroid Lab. They will light up corresponding with your charge level (e.g. 2 LEDs = 50%)

While charging, the LEDs will flash. When fully charged, and still plugged into a power source, the LEDs will be unlit

LED Film Counter

-  **Blinking rapidly**
No film inserted, or no shots remaining
-  **Solid lights**
Current film count (e.g. 4 LEDs = 4 shots remaining)

Rainbow LED Notifications

-  **No light**
Polaroid Lab off
-  **Slowly blinks 3 times**
Reading phone
-  **Rapid blink**
Realign phone
-  **Light on**
Ready for exposure

- A** Light sensor
- B** Platform release / ON button
- C** Shutter button
- D** Rainbow LED
- E** Film counter LEDs
- F** Film door
- G** Touch points
- H** Film Shield
- I** Battery level LEDs
- J** Micro-USB slot

